COAST®
LIGHTS • KNIVES • MULTI-TOOLS



HX5R

For warranty and distributor information in your country, visit: www.COASTportland.com

HX5R INSTRUCTIONS

BATTERY INSTALLATION:

The HX5R features our Dual Power Recharging system and can be powered by a rechargeable battery pack or a standard CR123 alkaline battery.

To install the rechargeable battery pack, unscrew the body of the light (near the power button) counterclockwise and place the rechargeable battery pack into the light in the direction indicated by the arrow on the battery pack; arrow towards the front of the light. Replace the body of the light and turn it clockwise to tighten it until it is fully closed.

To operate the light with a standard CR123 battery, place the battery into the light in the direction inside of the light. Replace the body of the light and turn it clockwise to tighten it until it is completely closed.

CHARGING:

Your HX5R is equipped with a USB. To expose the USB, grasp the tail cap of the light, turn counterclockwise until the stick is exposed. To charge your HX5R, simply plug the USB into any USB insert. When inserted, the charging indication light near the USB stick will glow. If the power indicator light is red, it indicates that the light is charging. If the power indicator light is green than the light is fully charged.

The HX5R can be charged using AC, DC or USB power. To use the AC adaptor, plug the USB connector into the power adaptor. To charge using USB, plug directly into a USB port.

Before first use, fully charge the rechargeable battery pack, inside of the light. The HX5R features overcharge protection, and it is not necessary to disconnect from power when fully charged. For added protection, the charging system will not work when the alkaline battery is installed inside the flashlight.

CAUTION: Use only the proprietary rechargeable battery pack that is included or a standard CR123 alkaline battery. Do not attempt to replace the rechargeable battery with aftermarket rechargeable battery packs. Do not dispose of in fire or short circuit the battery.

SWITCH OPERATION:

This flashlight is equipped with high, strobe and low light modes. To activate the high beam from the off position, press the on/off switch until it clicks once, then releases. Press the on/off switch until it clicks a second time to activate the low mode. Press the on/off switch until it clicks a third and final time to turn off the light.

The activate strobe light mode double click the on/off switch from the off position. Press the on/off switch one more time to turn off the light completely.

Any time the light is turned off for more than five seconds, the high/low cycle will reset, and the high beam will be activated when the light is turned on again.

PURE BEAM FOCUSING OPTIC with Slide Focus:

This flashlight is equipped with COAST's Pure Beam Focusing Optic with Slide Focus that allows the user to choose between a broad flood beam and a focused Bulls-Eye Spot beam for long distance illumination.

To adjust the beam into the Bulls-Eye Spot mode, slide the head of the light all the way forward.

To change the beam into the flood light mode, slide the head of the light all the way back.

The light includes a two-way clip that allows the user to clip to a hat brim or pocket.

MAINTENANCE:

Wipe the external body with a cloth moistened with water or isopropyl alcohol. Do not submerge.

18-522v01N 1806A